


Použití v interiéru v prostoru:





A



Nr.	kg	7074/03	7074/04	7074/05	7074/06	7074/07	7074/08	7074/09	7074/10	7074/11
0050879	10,0	-	-	-	-	-	-	4	4	8
0050985	15,0	-	-	-	-	-	-	-	-	-

Použití v exteriéru v prostoru:


B



Nr.	kg	7074/03	7074/04	7074/05	7074/06	7074/07	7074/08	7074/09	7074/10	7074/11
0050879	10,0	-	-	-	-	-	4	8	<del>XXXXXXXXXX</del>	
0050985	15,0	-	-	-	-	-	-			

Použití v interiéru u stěny:

C





Nr.	kg	7074/03	7074/04	7074/05	7074/06	7074/07	7074/08	7074/09	7074/10	7074/11
0050879	10,0	X	2	2	4	2	4	2	4	-
0050985	15,0	X	4	4	4	8	8	12	12	16
0050879	10,0	Y	-	-	-	-	-	2	2	4
0050985	15,0	Y	-	-	-	-	-	-	-	-

Použití v exteriéru u stěny:



D



Nr.	kg		7074/03	7074/04	7074/05	7074/06	7074/07	7074/08	7074/09	7074/10	7074/11
0050879	10,0	X	-	-	4	2	-	-	-		
0050985	15,0	X	-	4	4	8	12	16	-		
0050879	10,0	Y	-	-	-	-	-	2	-		
0050985	15,0	Y	-	-	-	-	-	-	-		
7072/41	0,6		-	-	-	-	-	-	2		

